

eve | plus

table base

Made in Belgium

Basalte is a registered trademark of Basalte bv.
Eve Plus is a registered trademark of Basalte bv.
Eve Plus is a registered design of Basalte bv.


basalte bv
fraterstraat 37b | 9820 merelbeke | belgium
tel +32 9 385 78 38 | info@basalte.be | www.basalte.be

Eve Plus table base installation manual

1. identification of the parts

Eve Plus table base 0151-xx

- A** table base
- B** plus connector
- C** adjustable angle
- D** cable route
- E** USB-C connector
- F** lock for the table mount
- G** USB-C charging cable (0093-19, included but also separately available)
- H** table mount




2. mounting the table base

1. Mark the location of the table mount using the provided template.
2. Screw the table mount on the table
3. Place the table base over the table mount.
4. a. Start with placing one corner in position
b. Push the other corner into a locked position.


important remarks

- USB-C power supply not included. For optimal charging, use in combination with the Puck - 24V DC - USB-C (0610-04).
- To upgrade to a PoE connection for your Eve Plus table base, add our Eve Gigabit PoE adapter (0610-21).
- The output power of the table base is 15 W.


1.




2.



3.



4.



template

